



Standardization Sequence

1. From the "Welcome" screen enter pass code "2 0 1 5".



2. From the "Options Screen", select "Standardize".



3. From the "Standardization" screen select "Start".



4. Insert the indicated Standardization standard into the unit.



5. Select "OK" and wait for the automated sequence to complete.



6. Verify "PASS" and remove/store the Standardization standard.

